

Deluxe Height Adjustable Computer Table **Assembly Instructions**

CTL 36", 48", 60" & 72"



How can we improve our assembly instructions?
Your comments and suggestions are important to us.
Please e-mail us at: support@versatables.com.

Deluxe Height Adjustable Computer Table

50mm Furniture Bolt



Qty:4

20mm Furniture Bolt



Qty:16

4mm Allen Wrench



Qty:1

Levelers



Qty:4

Caster & Caster with Lock



OPTIONAL

Qty:2

Leg Set



Qty:2

Cross Support



Qty:2

Zip Tie & Curly Tie



Qty:5

Kick Panel



Qty:1

Main Platform



24" & 30" Deep
36", 48", 60", & 72" Wide

Cable Management Tray



Qty:1

**NOTE: DO NOT TIGHTEN SCREWS/BOLTS ALL THE WAY
UNTIL THE PRODUCT IS COMPLETELY ASSEMBLED**

Step 1


Insert Levelers

Insert Levelers into Leg Sets

Leveling Glide



Qty:4



Step 2


Attach Cable Management Tray

Attach Cable Management Tray using (2) 20mm Furniture Bolts on each side.
Insert Bolts half way through the Leg Sets then drop the Cable Management Tray.

20mm
Furniture Bolt



Qty:4



20mm
Furniture Bolt

Step 3


Attach Kick Panel

Attach Kick Panel to Leg Sets using (4) 20mm Furniture Bolts.

20mm Furniture Bolt



Qty:4



20mm Furniture Bolt



Step 4


Attach Cross Support

Attach Cross Supports to Leg Sets using (2) 20mm Furniture Bolts on each side.


20mm Furniture Bolt



Qty:8



20mm Furniture Bolt



VersaTables.com
14105 Avalon Blvd.
Los Angeles, CA 90061



Lifetime Warranty



Quantity Discounts



Assembled in USA



Fast Shipping

Support:

Local: 310-353-7100
Toll Free: 888-929-0322
Fax: 310-353-7109
Support@VersaTables.com

Step 5


Main Surface

Lay the surface on the floor facing down and then flip the frame.
Attach Main Platform to Leg Sets using (2) 50 mm Furniture Bolts on each side.

50mm Furniture Bolts



Qty:4



50mm Furniture Bolt



NOTE : Two people may be needed to flip table upside down and then up again.